55 Hilton Street, Easton PA 18042
(269) 488-4000
www.alumilite.com

TECHNICAL DATA SHEET

Amazing Quick Coat

Amazing Quick Coat is a fast-curing, high-gloss resin designed to deliver flawless, crystal-clear finishes that enhance the vibrancy of any project. Whether you're sealing custom artwork, tumblers, or home décor, this easy-to-use resin ensures professional-quality results with minimal wait time.

With a simple 1:1 mix ratio, Amazing Quick Coat is perfect for creators who want bright, durable, and long-lasting finishes without the hassle. It cures to the touch in just 4-6 hours and reaches full hardness in 24 hours, making it an ideal choice for quick turnarounds. Designed for both beginners and professionals, this resin provides a smooth, glass-like surface that protects and elevates your creations.

PRODUCT SPECIFICATIONS	
Mix Ratio	1:1 by weight or volume
Mixed Viscosity	2800 cps
Working Time	15-20 minutes
Tack Free Time	4-5 hours
Demold Time	12 hours
Heat Deflection	130ºF
Hardness	81-D
Full Cure Time	3-5 Days
Tensile Strength	4470 psi
Elongation Strength	9%
Shelf Life	1 Year
Color	Clear

BEFORE USE: Thoroughly read Safety Data Sheets, product labels and the “SAFETY” section in this Technical Data Sheet.

55 Hilton Street, Easton PA 18042
(269) 488-4000
www.alumilite.com

IMPORTANT: PLEASE NOTE

- Amazing Quick Coat has a work time of 20-25 minutes based on a 100-gram sample at 70° F. Large amounts of mixed resin will shorten your work time as will warmer ambient temperatures. When mixing large volumes similar to a gallon, you can expect the open time to be cut in half. Mixing slowly, but adequately is important.
- Large amounts of mixed resin will shorten your work time as will warmer ambient temperatures. When mixing large volumes, you can expect the open time to be cut in half.
- We do not recommend pouring over bark, as bark can hold excessive air and moisture.
- This product should not be poured directly over an oil-based paint or stain, as oil and epoxy do NOT mix. There should be a definitive barrier between the two products. We suggest applying a waterbased clear coat over the oil-based product. If the water-based clear coat leaves a high gloss or shine, we suggest scuffing the surface with 320-grit to allow the epoxy to properly adhere. Once sanded, clean the surface thoroughly with Isopropyl Alcohol 99%. Then you can apply the epoxy.
- This product is not intended for permanent outdoor use or direct UV exposure.
- For instances where large surfaces are being coated and drill mixers will be used for mixing, vacuum degassing can be used to remove air from the resin before pouring onto surface. Vacuuming puts negative air pressure on the material and expands the air bubbles to a large size which gives them the buoyancy to float to the top and pop. Once mixed thoroughly and places under the vacuum, the air bubbles will come up and then go back down. Once bubbles go back down under full vacuum and begin to clear up, you may remove the mix container from the vacuum chamber and pour onto the surface.
- Paper products must be sealed prior to applying the resin as the resin could soak in and ruin the paper product. We recommend a solution of 4 parts white glue and 1 part water or Mod Podge to seal the paper.
- When mixing the resin and hardener, any cloudiness should clear up. If the product appears cloudy or is not crystal clear, contact our customer support team before applying to your final project.
- Amazing Quick Coat can be dyed or pigmented using non-water-based dyes. Alumilite.com offers transparent dyes, silicone color pigments, and Polycolor resin powders. These products produce vibrant and colorful effects when added to clear resins such as Alumilite Clear, Amazing Clear Cast, Amazing Deep Pour, and Amazing Quick Coat. We recommend testing in small amounts and adding more to brighten and deepen the color until the desired look is achieved. Application possibilities include beautiful river tables, blanks for wood turning, jewelry making, coasters, and more. If you are looking to use a dye, pigment, or filler that you have not used before, we highly recommend making a small test samples to ensure compatibility before using in your project.

BEFORE YOU BEGIN

Work Environment: The ideal working temperature is around 65-75°F in a clean, dry, dust-free environment. Avoid working in high humidity. If you are pouring in large volumes of 2 or more gallons,

we suggest keeping room temperature closer to 65°F. We highly recommend keeping fans on your project to help dissipate heat.

Materials: Be prepared with all necessary materials and tools before beginning your project.

- Stir-sticks
- Mold box
- Cleaning Materials
- Misc. handling tools – X-acto knife, pliers, a drill or Dremel tool, heat gun, etc.

Color – Dyes & Painting: Amazing Quick Coat can be dyed or pigmented using non-water base dyes. Alumilite offers a line of translucent dyes in standard colors that react/crosslink chemically with the resin to achieve beautifully translucent cast pieces with no worry of leaching or color ever coming out of the cured piece. Alumilite's Flourescent, White, and Black are not completely transparent as they contain some filler. When used in small quantities, they do not affect the transparency of the piece. However, if used in higher percentages, they can add opacity to the cast piece. Use very small amounts of dye to achieve bright translucent colored castings. If you are looking to use a dye, pigment, or filler that you have not used before, we highly recommend making a small test sample to ensure compatibility before using in resin.

Color Stability – Yellowing: As with all epoxy chemistry, AQC will develop a yellow hue over time. While there are UV inhibitors in our system that help it resist longer than some competitor products, a yellow hue will still develop over time. Many times this is not ever noticed based on the underlying surface color and the relative thin layer. Applications where AQC is applied over bright white surfaces or when pouring thicker layers, yellowing may be more evident. We generally do not recommend AQC for outdoor applications, as the UV exposure will cause the resin to develop a yellow hue rather quickly . There are some instances where it may be reasonable such as adding Alumilite dye or Alumidust to color the resin, which often times negates or minimizes the yellowing. Also applying it over certain toned wood surfaces that have more yellow and orange hues to it would make the yellowing less noticeable.

MIXING & POURING

Step 1: The mix ratio of the Amazing Quick Coat is 1:1 by volume. Using a graduated mixing container, measure equal parts per side. Varying the mix ratio will alter the cure and change the physical properties in negative ways such as tackiness or uncured surfaces. When mixing multiple batches, it helps to have a dedicated side A and side B measuring cup, which are then added to a larger mixing container.

Step 2: The material must be mixed thoroughly for 3-5 minutes. Be sure to scrape the sides, corners and bottom of container as you mix. Be careful not to whip excessive air into the mixture. If mixing a gallon, use a power mixer set to "hand speed". For smaller quantities, use stir sticks. Do not mix more than 3 gallons at one time. If you need to mix several batches, be sure to use a clean, dry container for

each batch. Using the same container may lead to curing issues.

Step 3: Pour the mixed resin into the mold or onto surface of project. Do NOT scrape out the last of the resin onto your project as unmixed epoxy on the sides or bottom of the container could contaminate your project, leading to curing issues.

Step 4: To remove air bubbles that have risen to the surface, use a heat gun or torch in a sweeping motion, holding the heat source approximately 6-10 inches away from the surface until no bubbles remain. Avoid heating any one spot for too long to prevent any distortions in the finish.

Step 5: Curing times can vary greatly by project, depending on mass and temperature. Open time ranges between 20-25 minutes, and full cure time is 3 days. Do not use or place any items on your project during this time.

Step 6 (optional): When used at room temperature, Amazing Quick Coat can be poured up to 1/8" at one time. Additional layers can be added 2 hours apart, but not beyond 12 hours without sanding in between layers. This can be repeated up to your desired thickness. Pouring beyond 1/8" in one pour can produce excessive exotherm that may cause bubbling, cracks, and deformations in the resin.

CLEAN UP & DISPOSAL

Tools can be cleaned with Isopropyl Alcohol 99% or a residue-free cleaner. Do not use soap and water. Dispose of product and container according to Federal, State and local regulations. Store any remaining product in the original bottles, tightly sealed and locked up in a cool, dry environment.

SAFETY

Safety: Before use, thoroughly read Safety Data Sheets and product labels. Follow safety precautions and directions.

- Wear gloves
- Safety glasses
- Protect clothing with a work smock or other outer garment
- For cleaning surfaces, containers – use Acetone, rubbing alcohol or nail polish remover
- When stored separately, epoxy & hardener have long shelf lives – store in a cool dry area in tightly sealed containers

Part A: Keep out of reach of children. Wear impervious gloves, such as butyl rubber or nitrile rubber. Wash skin thoroughly with soap and water after handling. Take off contaminated clothing and wash it before reuse. If skin irritation occurs, get medical help. Wear eye protection, such as chemical safety glasses/googles. If in eyes, rinse cautiously with water for several minutes, removing contact lenses if present and easy to do. If eye irritation persists, get medical help.

Part B: Keep out of reach of children. Do not eat, drink, or smoke when using this product. If swallowed, rinse mouth and get medical help. Use with adequate general or local exhaust ventilation to minimize exposure levels. If needed, a NIOSH-approved respirator with organic vapor cartridge may be used. Wear impervious gloves, such as butyl rubber or nitrile rubber. Wash skin thoroughly with soap and water after handling. Wear eye protection, such as chemical safety glasses/googles. If in eyes, immediately rinse with water for several minutes, removing contact lenses if present and easy to do. If eye irritation persists, get medical help.

WARNING: THE CURE REACTION IS EXOTHERMIC. Do not apply in thicknesses greater than the recommended maximum application thickness for the product.

DISCLAIMER: The information contained herein is considered accurate; however, Alumilite makes no warranty regarding its accuracy. The user must determine the suitability of the product for the intended use and accepts all risk and liability associated with that use.